



TASTENBELÄGE

key coverings


Form A




sharps overlay
Obertastenauflage
placage d. rehausses
base d. l. tecl. superiores




sharps
Obertasten
revêtement d. rehausses
forro d. l. tecl. superiores




naturals
Untertasten
revêtement d. notes naturelles
forro de teclas inferiores




Form B




sharps overlay
Obertastenauflage
placage d. rehausses
base d. l. tecl. superiores




sharps
Obertasten
revêtement d. rehausses
forro d. l. tecl. superiores




naturals
Untertasten
revêtement d. notes naturelles
forro de teclas inferiores




Form A2




sharps overlay
Obertastenauflage
placage d. rehausses
base d. l. tecl. superiores




sharps
Obertasten
revêtement d. rehausses
forro d. l. tecl. superiores




naturals
Untertasten
revêtement d. notes naturelles
forro de teclas inferiores




Form NI




sharps overlay
Obertastenauflage
placage d. rehausses
base d. l. tecl. superiores




sharps
Obertasten
revêtement d. rehausses
forro d. l. tecl. superiores




naturals
Untertasten
revêtement d. notes naturelles
forro de teclas inferiores




Form R




sharps overlay
Obertastenauflage
placage d. rehausses
base d. l. tecl. superiores




sharps
Obertasten
revêtement d. rehausses
forro d. l. tecl. superiores




naturals
Untertasten
revêtement d. notes naturelles
forro de teclas inferiores




Form E



sharps overlay
Obertastenauflage
placage d. rehausses
base d. l. tecl. superiores



sharps
Obertasten
revêtement d. rehausses
forro d. l. tecl. superiores



naturals
Untertasten
revêtement d. notes naturelles
forro de teclas inferiores

